


INDEPENDENT MOUNT HANDGUARDS



- 1 At this time look over your bikes controls and decide which mounting method will work best for your specific needs. If you like your perch so your levers are low you may want to consider running the bracket over your levers (diagram A-1). If you like your perches so your lever are high you may choose to run the brackets under your levers (diagram A-2).
- 2 No matter how you choose to mount your brackets the "L" should be open to the end of the handlebar.
- 3 To begin the installation use the appropriate Stealth bracket, "C" clamp, and (2) 5mm phillips head clamp bolts. Position the Stealth Bracket



4 - Follow this same procedure on the other side of the handlebar.

5 - Locate appropriate handshield and decide which mounting holes will position the handshield for best protection. Next, position plastic bolt plate over upper (B-1) or lower (B-2) mount holes of the plastic handshield and insert 5mm button head allens through the bolt plate, through the handshield and thread into the Stealth bracket (C-1). It is a very highly suggested that thread lock or loc-tight be used

